

**Battery for cordless saw transmitter (AA/R6)
1.2V DC 1900mAh****PHOTO**

Nominal voltage: 1.2 V DC
Battery capacity: 1900 mAh
Battery size: AA
Dimensions: (50,5 x 14,5) mm
Weight: 27 g

DESCRIPTION

Ni-MH cells of AA size and 1900 mAh capacity. The capacity of the batteries was tested based on the IEC 61951-2 standard. The batteries feature a wide operating temperature range (from -20°C to 50°C) and high durability.

APPLICATION

The batteries are used to power the **A443.0202** cordless saw transmitter. Two batteries are required to power the transmitter.

STORAGE AND MAINTENANCE

After finishing work, the transmitter (remote control) should be turned off by turning the ignition switch to the OFF position to slow down the battery discharge process. The saw and its accessories (charger, batteries, remote control, etc.) should be stored in a carrying case in a way that protects them from mechanical damage. Store the set in dry rooms, away from heat sources, in a chemically non-aggressive atmosphere. Protect from sunlight.

Battery for cordless saw transmitter (AA/R6)
1.2V DC 1900mAh**EXAMINATION**

Periodically visually inspect the battery and check its correct operation. The visual inspection includes checking for:

- No visible damage to the battery casing.
- No visible damage to the battery contacts.

Damaged batteries (mechanically or electrically) cannot be used for work.

FREQUENCY OF TESTS

Carry out periodic inspections according to the table below.

| | PERIODIC INSPECITON |
|------|---|
| Who | Supervision |
| When | Once a year |
| How | Visually (visual inspection) and manually (correct operation) |

* Unless the instructions for organizing live working state otherwise